



American Aviation Corporation
318 Bishop Road Cleveland, Ohio 44143

SERVICE

Accessory Kit No. AK-103A
(Supersedes Accessory Kit No. AK-103)

DATE:

January 27, 1971
APR 26 1969

TITLE:

Sun Screen Accessory Kit

MODELS AFFECTED:

AAI-0001 and up, AIA-0001 and up.

WEIGHT AND BALANCE CHANGE:

Weight Increase 2.50 LB.
Arm 87.00 IN.

Parts List

Quantity	Part Number	Description
1	804026-502	Sun Screen Assy
8	804026-2	Clip
8	804026-3	Clip
8	AN960-8	Washer
8	MS24693-S53	Screw
3	MS20365-832	Nut

Description of Installation

1. Installation of plexiglass sun screen and related attaching hardware.
2. Estimated time to accomplish this installation is 1.5 man hours.

Installation Instructions (Refer to Figure 1)

1. Loosen the top eight screws which attach the canopy skirt to the aft canopy bow. This includes the two forward screws that go through the bow and into the canopy handles.
2. Insert the notched ends of the 804026-3 clips between the vinyl foam tape gasket and the aft canopy bow at each screw location.
(Note: A razor, wire or thin-bladed knife can be worked between the two surfaces to allow insertion of the clips. Exercise caution to prevent cracking the plexiglass.)
3. Tighten these eight screws. Do not over-tighten.
4. Remove the top eight screws which attach the canopy plexiglass to the forward canopy bow and replace with the MS24693-S53 screws supplied in this kit. To avoid relative movement between parts, replace screws one at a time.
5. Insert the sun screen into the aft clips and position in the center of the canopy.
(Note: The forward edge of the sun screen is denoted by the masking tape on the screen itself.)

Changes: Added AIA-0001 to MODELS AFFECTED. This kit is also applicable to the AIA American Trainor

A
C
C
E
S
S
O
R
Y

K
I
T

U.S. AIR FORCE
Air Materiel Control
Supply Division
Wright-Patterson Air Force Base
Dayton, Ohio 45433

SERVICE

6. Turn the forward end of the sun screen up and hold it in place and install the 804026-2 clips using the MS20365-232 nuts and AN960-3 washers supplied in this kit.
7. Position the sun screen so that the edges are even with the edge of the clips on each side before tightening the nuts.

Sun Screen CAUTION

Over-tightening of screws or excessive pressure on the plexiglass can cause cracking.




Figure 1: SUN SCREEN ASSY AND INSTALLATION KIT ASSEMBLY